

R6 Chain Puller

!For CLOSED CURCUIT use only!

!Close Axle 140 Nm!

1. Remove the rear wheel.
2. Remove the chain pullers screws.
3. Loosen screws. (1)
4. Fix the YART chain pullers to the swingarm on both sides with screw (2). (23 Nm, use grease)



5. Close screws (1). (3 Nm)
6. Install the rear wheel, don't forget the washer between the chain puller and the wheel nut.
7. Adjust the chain pull by turning the allen screw.
8. Close the axle with 140 Nm.
9. Check the functionality of the wheel and brake.